



OMOS

v32t
Chair

www.omos.ie
+ 353 45 899 802



v32t Chair



DESCRIPTION

Chair with profile cut steel ends and cross connecting bars, hot dipped galvanized and powder coated. Screwless hardwood laths surface profiled for water run-off.

DIMENSIONS

Width 605mm, Depth 713mm, Height 830mm (Seat Height 455mm).

OPTIONS

Unfinished hardwood or microporous coating. Choice of RAL colours for powder coating. With or without armrests.

Constructed from powder coated galvanized steel and capped with hardwood slats, the delicate proportions of the timber and their high frequency create a refined lightweight aesthetic.

The profile-cut steel ends and intermediate supports, connected by bars on the edge, provide support to each individual timber slat, belying its delicate appearance. The narrow curved profile of timber ensures moisture dissipates quickly from the bench surface. The chair is available with or without armrests.

The chair can be left free standing as well as root or tab fixed to the ground.



v32t Chair Fixing Instructions


TAB FIXING

FOR AREAS ALREADY PAVED

1. Determine the location for the chair. Remove the pavers and excavate a hole. The size of the foundation may vary depending on the ground conditions.
2. Fill the holes with 35N20 concrete up to 15mm below the level of the underside of the pavers ensuring a good smooth surface finish.
3. Allow sufficient time for the concrete to set then apply a layer of dry sand/cement mix over the pad. Compact and adjust to bring this to the level of the underside of the paving.
4. Replace the paving slabs and ensure that they are well bedded in.
5. Place the chair in the desired location and mark through the fixing holes making sure this is done accurately.
6. Remove the chair and drill through the paving slabs into the concrete pad below. Drill following fixing manufacturer's instructions to suit the chosen fixing. Choose a fixing which will accept an M8 SS CSK bolt, either a mechanical anchor (such as RS PRO Stainless Steel Drop In Anchor M8 x 30mm) or an internally threaded fixing designed for chemical fixing (such as Hilti HIS-RN M8xL [length to suit]). IMPORTANT, the depth of the hole must be sufficient to allow the fixing to be fully embedded in the concrete rather than partially in the paver and partially in the concrete.
7. Insert the fixings into the ground following fixing manufacturer's instructions. Reposition the chair and screw in M8 SS CSK bolt into the 4 no. fixings. Where chemical fixing is used (such as Hilti HIT-HY 150) leave sufficient time to cure before. Tighten the bolts

FOUNDATIONS

The v32t chair can be fixed directly to a concrete slab or to concrete pads beneath paving stones. Foundations must be to engineer's specification.



v32t Chair Fixing Instructions


ROOT FIXED

FOR AREAS ALREADY PAVED

1. Determine the location for the chair. Remove the pavers and excavate a hole. The size of the foundation may vary depending on the ground conditions.
2. Fill the holes with 35N20 concrete up to 15mm below the level of the underside of the pavers ensuring a good smooth surface finish.
3. Allow sufficient time for the concrete to set then apply a layer of dry sand/cement mix over the pad. Compact and adjust to bring this to the level of the underside of the paving.
4. Replace the paving slabs and ensure that they are well bedded in.
5. Place the chair in the desired location and mark around the four threaded fixings.
6. Remove the chair and drill 12mm holes through the paving slabs into the concrete pad below. Perform a dry fit to ensure the drilled holes are correctly positioned.
7. Using an injectable adhesive anchor such as Hilti HIT-HY 200-A and following manufacturers instructions, inject into the four holes.
8. Reposition the chair ensuring it is fully seated. Remove any excess adhesive which may have been displaced by the anchor bars.

FOUNDATIONS

The v32t chair can be fixed directly to a concrete slab or to concrete pads beneath paving stones. Foundations must be to engineer's specification.



Hardwood Finishes



MICROPOROUS COATED

The board in the top half of the image is Iroko hardwood with a factory applied microporous stain. This finish offers very good resistance to UV rays as well as enriching and enhancing the hardwood's rich colour. Provided the coating surface does not become broken, the colour will not fade for several years. The microporous coating is however vulnerable to conditions where high moisture and severe cold persists. Conditions as these such can cause the coating to blister and lift.

UNTREATED

The board in the bottom half of the image is Iroko hardwood that has been freshly sanded and left untreated. When left untreated, the hardwood begins to fade within weeks of exposure to sunlight. After some time the timber begins to change to a silver-grey achromatic colour. Despite the difference in appearance, the timber remains structurally sound due to its inherent durability.

Maintaining Microporous Coated Hardwood



MAINTENANCE

The microporous coated hardwood should be cleaned regularly using mild detergents. After sometime maintenance of the finish is required. To determine the necessary course of action, first assess the condition of the coating and follow the instructions below. We have chosen the three most common conditions that may occur with microporous coatings.

1. COATING HAS FADED EVENLY ACROSS THE HARDWOOD BUT HAS NOT BLISTERED OR FLAKED.

Clean the hardwood thoroughly with soapy water and a scouring pad. Lightly sand the surface. If the coating flakes or is easily removed by sanding, follow the steps detailed for instructions 2 or 3. Apply Sikkens Cetol Filter 7 Plus using a brush. Always follow the coating manufacturers instructions carefully.

2. COATING HAS BLISTERED OR FLAKED BUT IN SMALL PATCHES ONLY (2-3 SQ CM).

Where small areas have blistered, this area should be sanded back locally to bare hardwood. Apply Sikkens Cetol Filter 7 Plus, colour 085 Teak to the sanded area only. Once dry, lightly sand all the timber and apply two coats of Sikkens Cetol Filter 7 Plus across the entire timber surface. Always follow the coating manufacturers instructions carefully.

3. COATING HAS BLISTERED OR FLAKED ACROSS LARGE AREAS.

Where large areas have blistered or flaked, that damaged face should be sanded back to bare hardwood. Apply two or three coats of Sikkens Cetol Filter 7. Always follow the coating manufacturers instructions carefully.

Maintaining Unfinished Hardwood



MAINTENANCE

Iroko is an extremely durable hardwood and does not require maintenance to preserve its structural properties. Without maintenance, although it will turn grey, as seen in the left hand side of image above, the structural properties of the timber will not diminish. However, in order to preserve the colour of the timber, regular maintenance is required in the form of cleaning and, if desired, the application of oil or a microporous coating.

Cleaning can be done using a number of methods. For regular cleaning use a scrubbing brush or scouring pad with warm water and a mild detergent. Take care to avoid contact with any metal or painted surfaces on the product when using an abrasive method of cleaning. Timber that has been left for some time unmaintained can be restored using a wood cleaner/restorer product such as Owatrol Net-trol Wood Cleaner and Brightener. Such products are widely available, when applying follow the product's user instructions carefully.

The timber can be brought back to its natural colour by sanding. Start with a coarse sanding block (60 grit) and work up through the grades to finish with 120 grit.

Maintaining Powder Coating



MAINTENANCE

Polyester powder coating is a dry finishing process where a polyester resin powder is applied and then baked onto the surface. This creates a durable, protective finish that resists corrosion, weathering, and UV damage. Its versatility allows for a wide range of colour choices, ensuring vibrant and long-lasting aesthetics for diverse applications.

Despite the powder coating durable properties, some care is required to maintain the appearance of the material. The extent to which maintenance is required will depend on a number of factors including environmental conditions, construction activity and level of use.

To maintain the original appearance of the metalwork it should be cleaned regularly using warm soapy water. Avoid the use of abrasive cleaners as they may damage the surface finish.

Should the paint become chipped or scratched it can be touched up using a colour matching metal paint. Where the surface becomes damaged clean with a wire brush or sand, then paint with an outdoor metal paint, Omos recommends Uni 2k paint which can be purchased from most industrial or automotive paint suppliers. We recommend testing on a hidden area to ensure a good colour match before applying to the damaged region. For further advice contact Omos.